

Always
check pattern
BEFORE
leaving the shop!

1. Check pattern in shop FIRST!



2. Tape one edge of the template to surface with masking tape and unroll it. Level the template and tape the other edge to the installation surface



3. Mark holes with center punch, then drill 1/4" holes 3" deep where indicated on your template. Remove the template and clean out all drill holes using any of the following methods: a quick puff of air; using the vents on your drill; compressed air or a turkey baster



4. Insert the studs into the stud holes on the back of each letter. Place letters in holes on wall before applying silicone to verify position. Adjust as necessary. now fill the drill holes in the wall of the first letter with silicone.



5. Push the tube of silicone over each stud on the first letter in order to evenly coat it with adhesive.



6. Push the letter into the drill holes using a shim to assure the proper standoff of the letter from the wall. Repeat steps 3 through 5 for the rest of the letters.